

## 8 inch ProBlock Installation Example 16 inch □C reinforcement

- ProBlock can be used open end to open end, open end to closed end or closed end to closed end.
- The grouted cell should be formed using an open end and closed end whenever possible to minimize grout use.
- Special units such as corners, halves and bond beams use the same as those used with regular units.
- Grouting spacing, opening and control joint locations will vary and all situations can be accommodated using ProBlock and regular units.
- ProBlock units are produced with both sash ends and square ends to accomadate control joints and openings.

